

FOUR WHEEL HINGED PIPE CUTTER REPLACEMENT PARTS



Ref	Description	Qty
1.	Upper Yoke	1
2.	Lower Yoke	1
3.	Crosshead	1
4.	Handle & Screw	1
5.	Latch	1
6.	Guide	2
7.	Crosshead Locknut	1
8.	Set Screws	2
9.	Guide Spring	2
10.	Latch Spring	1
11.	Thrust Washer	1
12.	Wheel pin	4
13.	Guide Pin	2
14.	Latch Pin	1
15.	Lower Yoke Pin	1
16.	Locknut	1
17.	Hinge Bolt	1
18.	Handle Grips	2
19.	Cutter Wheel	4
20.	Crosshead Assembly	1

